




# Air Windshield Remover

Item No : QK-111



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



## Part List QK-111

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	01	QK-111P01	Plug	1
▲	02	QK-111P02	626 Ball Bearing	1
★	03	QK-111P03	Head Housing	1
▲	04	QK-111P04	6000 Ball Bearing	1
▲	05	QK-111P05	Seal-Oil	1
★	06	QK-111P06	Clamp Nut	1
▲	07	QK-111P07	Working Spindle	1
●	08	QK-111P08	Blade	1
★	09	QK-111P09	Blade Clamp	1
▲	10	QK-111P10	Fork Drive	1
x	11	---	607 Ball Bearing	1
x	12	---	Shake Crank	1
★	13	QK-111P13	Nut	1
★	14	QK-111P14	Motor Bearing Cap	1
▲	15	QK-111P15	Set Screw	1
x	16	---	6000 Ball Bearing	1
x	17	---	Front End Plate	1
▲	18	QK-111P18	Bearing Spacer	1
▲	19	QK-111P19	Rotor	1
●	20	QK-111T20	Rotor Blade (4 pcs)	1 set
▲	21	QK-111P21	Cylinder	1
x	22	---	Rear End Plate	1
x	23	---	626 Ball Bearing	1
★	24	QK-111P24	Throttle Lever	1
x	25	---	Motor Housing	1
●	26	QK-111T26	O-Ring (2 pcs)	1 set
▲	27	QK-111P27	Valve Stem	1
▲	28	QK-111P28	Valve Spring	1
▲	29	QK-111P29	Air Regulator	1
▲	30	QK-111P30	O-Ring	1
▲	31	QK-111P31	O-Ring	1
▲	32	QK-111P32	Throttle Valve Plug	1
x	33	---	Throttle Valve Bushing	1
★	34	QK-111P34	Exhaust Deflector	1
▲	35	QK-111P35	Air Inlet Hose	1
▲	36	QK-111P36	Exhaust Hose	1
★	37	QK-111P37	Lubricator Cap	1
▲	38	QK-111P38	O-Ring	1
▲	39	QK-111P39	Circlip	1
★	40	QK-111P40	Spring Pin	1
x	41	---	Roller Pin	2
★	42	QK-111P42	Wrench	1
★	43	QK-111P43	29 mm Spanner Wrench	1
●		QK-111T01	Shake Crank Assembly (11.12)	1 set
▲		QK-111T02	Front End Plate Assembly (16.17.41)	1 set
▲		QK-111T03	Rear End Plate Assembly (22.23.41)	1 set
★		QK-111T04	Motor Housing Assembly (25.33)	1 set